

LAVE-LINGE HUBLOT LF512-L2B _ 8008938

SCHEMA F2 AC PTC

Alimentation

**Ana Kontrol Karti
Main Control Board**

K1, K2, K3, K4, K5

X1, X2, X3, X4, X5, X6, X7, X8, X9, X10, X11, X12, X13, X14, X15, X16, X17, X18, X19, X20, X21, X22, X23, X24, X25, X26, X27, X28, X29, X30, X31, X32, X33, X34, X35, X36, X37, X38, X39, X40, X41, X42, X43, X44, X45, X46, X47, X48, X49, X50, X51, X52, X53, X54, X55, X56, X57, X58, X59, X60, X61, X62, X63, X64, X65, X66, X67, X68, X69, X70, X71, X72, X73, X74, X75, X76, X77, X78, X79, X80, X81, X82, X83, X84, X85, X86, X87, X88, X89, X90, X91, X92, X93, X94, X95, X96, X97, X98, X99, X100

Résistance

Pompe de vidange

P

Sécurité de porte

**Electrovanne
PW (Pré-lavage)
W (Lavage)**

CP

Pompe Twinjet

Sonde température

NTC

Pressostat

Moteur AC

1 3 2

8 7 6 5 4 3 2 1

STATOR STATOR ROTOR ROTOR THERO THERO

**X1 = Alimentation
X2 = Moteur
X3 = Sécurité de porte
X6 = Résistance
X7 = Sonde température
X10 = Pompe de vidange
X11 = Electrovanne Pré-lavage + lavage
X12 = Pompe Twinjet
X13 = Pressostat EPS**