

**Important**

Read this user manual carefully before you use the appliance and save it for future reference.

**Danger**

- Never immerse the appliance in water.
- To prevent a short circuit or an electric shock, do not use water to rinse the outside of the pot unit or top unit (including handgrip, control panel, motor unit connector, jug connector, and main cord socket) and keep them away from drip or splash.

- Make sure the surface of both motor unit connector and jug connector is free from liquid or any conductive medium before putting the motor unit onto the jug.

**Warning**

- Keep the appliance and its mains cord out of reach of children when the appliance is switched on or cooling down.

- Keep the appliance and the mains cord away from hot surfaces.

- The temperature of accessible surfaces is high when the appliance is operating. Do not touch the surface of the jug or other parts that are hot after use (Fig. 2).

- Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance.

- Do not use the appliance if the plugs, the mains cord or the appliance itself are damaged.

- Only the cord set provided by Philips can be used.

- Make sure that your hands are dry when you insert the mains cord into the appliance and in the wall socket.

- This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.

- This appliance can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.

- Children should be supervised to ensure that they do not play with the appliance.

- This appliance can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.

- Children should be supervised to ensure that they do not play with the appliance.

- Do not use abrasive clean agents to clean the surfaces in contact with food.

- This appliance is intended for household use only. If the appliance is used improperly or for professional or semi-professional purposes or if it is not used according to the instructions in the user manual, it may cause potential injury, and the guarantee becomes invalid and Philips refuses any liability for damage caused.

- Always place the appliance on a dry, flat and stable surface.

- Only connect the appliance to an earthed wall socket.

- Never use any accessories or parts from other manufacturers or that Philips does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.

- This appliance is not intended to be operated by means of an external timer or a separate remote-control system.

- Always disconnect the appliance from the supply if it is left unattended and before assembling, disassembling or cleaning.

- Do not let the appliance run unattended.

- Do not operate the appliance continuously.

- Do not let the appliance operate when it is empty.

- Never add contents (including liquid) above the MAX or below the MIN indication.

- Beware of hot steam coming out of the edge of the lid during processing, or hot steam coming out of the appliance when you remove the motor unit after preparing hot soup.

- Do not touch the blades. The blades are very sharp.

- Do not lift the motor unit and move the appliance when it is operating.

- This appliance is not suitable for frozen ingredients.

- Always defrost the ingredients before putting into the jug.

- This appliance is not suitable to heat up milk.

- Always hold the appliance by the handle on the jug. Do not hold the appliance by the handgrip on the motor unit, as it may tip over. (Fig. 3)

- Always hold the appliance by the handle on the jug. Do not hold the appliance by the handgrip on the motor unit, as it may tip over. (Fig. 3)

- Always hold the appliance by the handle on the jug. Do not hold the appliance by the handgrip on the motor unit, as it may tip over. (Fig. 3)

- Always hold the appliance by the handle on the jug. Do not hold the appliance by the handgrip on the motor unit, as it may tip over. (Fig. 3)

- Always hold the appliance by the handle on the jug. Do not hold the appliance by the handgrip on the motor unit, as it may tip over. (Fig. 3)

- Always hold the appliance by the handle on the jug. Do not hold the appliance by the handgrip on the motor unit, as it may tip over. (Fig. 3)

- Always hold the appliance by the handle on the jug. Do not hold the appliance by the handgrip on the motor unit, as it may tip over. (Fig. 3)

- Always hold the appliance by the handle on the jug. Do not hold the appliance by the handgrip on the motor unit, as it may tip over. (Fig. 3)

- Always hold the appliance by the handle on the jug. Do not hold the appliance by the handgrip on the motor unit, as it may tip over. (Fig. 3)

**General description (Fig. 1)**

- Handgrip
- Motor unit
- Overflow sensor
- Blade unit
- Jug

- Pureed soup program with light - 18 minutes
- Chunky soup program with light - 18 minutes
- Compote program (heating only) with light - 12 minutes
- Smoothie program (blending only) with light - 3 minutes
- Manual blending program with indicator light
- Program selection button
- Start/stop button
- Motor unit connector
- Jug connector
- Level indicators (The MAX and MIN indications are on the inside of the jug.)
- Handle
- Power cord socket
- Power cord

**Preparing for use**

Clean the appliance before you use it for the first time.

- Hold the handle of the jug with one hand and with the other hand lift the motor unit off the jug by its handgrip (Fig. 4).
- Fill the jug with water up to the MAX indication (Fig. 5).
- Hold the motor unit above the jug with both connectors aligned and then lower the motor unit into the jug (Fig. 6).
- Put the small plug in the socket of the jug (1) and put the mains plug in the wall socket (2) (Fig. 7).
- Press the program selection button repeatedly to select the compote program (Fig. 8) and then press the start/stop button (Fig. 9).
- The compote light goes on (Fig. 10).
- When the program has finished, the appliance beeps and the compote light blinks.
- Hold the handle of the jug with one hand and with the other hand lift the motor unit off the jug by its handgrip (Fig. 4).
- Pour the water out of the soup jug and rinse the inside of the jug under the tap (Fig. 11).

**Note**

- Never immerse the appliance in water.

**Using the appliance**

The SoupMaker has a blade unit for blending ingredients and a heating element to heat the ingredients to cook soup. You can also use the appliance to make compotes or smoothie. It has four preset modes and a manual program button. Various recipes and tips are available in the separate recipe booklet.

The general steps below apply to all five programs.

- Prepare the ingredients.

**Tip**

- For best taste, use fresh seasonal ingredients.
- Cut the ingredients in cubes of 2cm to get perfect results.
- Defrost ingredients before putting them in the jug.
- This appliance is not suitable for making pastry such as making batter, or baking.

- Hold the handle of the jug with one hand and with the other hand lift the motor unit off the jug by its handgrip (Fig. 4).
- Put the ingredients in the jug (Fig. 12).

**Note**

- If you are cooking meat and vegetables, make sure you put the vegetables in the jug first.
- Make sure the ingredients are spread evenly over the bottom of the jug.

- Add water or another liquid to the ingredients in the jug (Fig. 12).

**Caution**

- Make sure the content (including liquid) is somewhere between the MIN and MAX indication.

- Stir the liquid and ingredients (Fig. 13).

- Hold the motor unit above the jug with both connectors aligned and then lower the motor unit into the jug (Fig. 6).

- Put the small plug in the socket of the jug (1) and put the mains plug in the wall socket (2) (Fig. 7).

- Press the program selection button to select the desired program (Fig. 8).

- Press the start/stop button to start the cooking process (Fig. 9).

- The corresponding light goes on and the SoupMaker starts the cooking and/or blending process (Fig. 10).
- When the program has finished, the appliance beeps, and the indicator light blinks (Fig. 14).

**Tip**

- If you prefer your soup even finer, or would like to do some blending in your chunky soup or compote, select the manual blending program. Press and hold the start button to start blending. To stop blending, simply release the start button.

**Note**

- To stop the ongoing cooking process, press and hold the start/stop button for 2 seconds.
- The maximum operating time for one manual blending cycle is 30 seconds.
- To keep the appliance more durable, wait at least 30 minutes until the appliance cools down before next use.

- Remove the power plug from the wall socket and from the appliance (Fig. 15).

- Hold the handle of the jug with one hand and with the other hand lift the motor unit off the jug by its handgrip (Fig. 4).

- You can now pour the soup, smoothie or compote into a bowl (Fig. 16).

**Note**

- Clean the appliance after every use. Refer to the chapter 'Cleaning'.

**Cleaning****Caution**

- Never immerse the appliance in water. Do not clean the appliance in the dishwasher.
- Keep both the motor unit connector and jug connector clean and dry.

**Note**

- Always unplug the appliance and wait until it cools down before you clean it.
- Never use scouring pads, abrasive cleaning agents or aggressive liquids such as petrol or acetone to clean the appliance.

- Remove the mains plug from the wall socket and from the appliance (Fig. 15).

- Hold the handle of the jug with one hand and with the other hand lift the motor unit off the jug by its handgrip (Fig. 4).

- Clean the blade unit and overflow sensor by rinsing them under the tap (Fig. 17).

**Note**

- Do not touch the blades. The blades are very sharp.

**Tip**

- If necessary, clean the blade unit and overflow sensor with a soft brush.

- Clean the inside of the jug under the tap. If necessary use a soft brush (Fig. 18).

- Clean the top part of the motor unit and the outside of the jug with a moist cloth (Fig. 19).

**Tip**

- If the appliance and the blade unit are very dirty, pour boiling hot water into the jug and place the motor unit on the jug. Let the jug and the motor unit soak for 10 minutes.

**Storage**

- Dry the jug and motor unit before storage.
- Store the appliance in a cool, dry place away from direct sunlight or other heat source.

**Technical specifications****Note**

- The product information below is subject to change without prior notice.

Rated voltage: 230V  
 Rated frequency: 50Hz  
 Motor power: 120W  
 Heating power: 1000W  
 Dimensions:  
 - SoupMaker: 205x153x310mm  
 - Packaging: 220x220x340mm  
 Weight:  
 - Net weight: 2.1kg  
 - Gross weight: 3.0kg  
 Capacity: 1200ml (for 2-4 persons)

**Recycling**

- This symbol means that this product shall not be disposed of with normal household waste (2012/19/EU) (Fig. 20).
- Follow your country's rules for the separate collection of electrical and electronic products. Correct disposal helps prevent negative consequences for the environment and human health.

**Guarantee & service**

If you need service or information or if you have a problem, please visit the Philips website at [www.philips.com/support](http://www.philips.com/support) or contact the Philips Consumer Care Center in your country. You find its phone number in the worldwide guarantee leaflet. If there is no Consumer Care Centre in your country, go to your local Philips dealer.

**Troubleshooting**

This chapter summarises the most common problems you could encounter with the appliance. If you are unable to solve the problem with the information below, visit [www.philips.com/support](http://www.philips.com/support) for a list of frequently asked questions or contact the Consumer Care Center in your country.

Problem	Cause	Solution
The light of the selected mode does not go on.	There is a connection problem.	Make sure the small plug is inserted in the appliance properly, the mains plug is inserted in the wall socket properly and the motor unit fits onto the jug properly.
The light of the selected program is on, but the appliance does not work.	You have not pressed the start button.	Press the start/stop button.
The appliance makes alarm sounds at the beginning.	You have put ingredients over the MAX indication in the jug.	Remove some of the ingredients (Follow the user manual instruction or the recipe booklet).
The appliance stops working and makes alarm sounds during the cooking process.	The food is burnt on the bottom of the jug.	Remove the ingredients and clean the burnt area. Follow the recipe booklet to restart the program.
The appliance stops working during the cooking process.	You have started the program without adding ingredients and/or liquid.	Add the ingredients and/or liquid before starting the program (Follow the user manual instruction or the recipe booklet).
The appliance stops working during the cooking process.	The motor unit is detached from the jug during the cooking process, as too many ingredients are put in the jug or the ingredients are overzested.	Remove some of the ingredients and cut the ingredients into 2x2x2cm pieces (Follow the user manual instruction or the recipe booklet).
The appliance overflows.	You have put ingredients over the MAX indication.	Remove some of the ingredients (Follow the user manual instruction or the recipe booklet).
The program has completed but the ingredients have not been blended well.	The ingredients used are not recommended.	Follow the user manual instruction or the recipe booklet.
	You have put too many ingredients in the jug or used overzested ingredients.	Remove some of the ingredients and cut the ingredients into 2x2x2cm pieces (Follow the user manual instruction or the recipe booklet).
	You have used frozen ingredients.	This appliance is not suitable for frozen ingredients. Always defrost the ingredients before putting into the jug.
	You have been using the appliance continuously.	Leave the appliance to cool down for at least 30 minutes.
	The motor does not work when using Smoothie or Manual blending program.	You have been using the appliance continuously. Leave the appliance to cool down for at least 30 minutes.

**Wichtig!**

Lesen Sie diese Bedienungsanleitung vor dem Gebrauch des Geräts aufmerksam durch, und bewahren Sie sie für eine spätere Verwendung auf.

**Achtung!**

- Tauchen Sie das Gerät niemals in Wasser!
- Um einen Kurzschluss oder elektrischen Schlag zu vermeiden, spülen Sie die Außenseite des Suppentopfes oder des Geräts (einschließlich Handgrip, Bedienfeld, Anschluss der Motoreinheit, Verbindungsstück der Kanne und Buchse des Netzkabels) nicht mit Wasser ab, und halten Sie die Teile fern von tropfendem oder spritzendem Wasser.

- Stellen Sie sicher, dass die Oberfläche des Anschlusses der Motoreinheit sowie des Verbindungsstücks der Kanne frei von Flüssigkeiten und leitenden Materialien sind, bevor Sie die Motoreinheit auf die Kanne setzen.

- Halten Sie das Gerät und das Netzkabel außerhalb der Reichweite von Kindern, wenn das Gerät eingeschaltet ist oder abkühlt.

- Halten Sie das Gerät und das Netzkabel fern von heißen Oberflächen.

- Die Temperatur der zugänglichen Oberflächen ist hoch, wenn das Gerät in Betrieb ist. Berühren Sie keinesfalls die Oberfläche der Kanne oder andere Teile, die nach der Verwendung heiß sind (Abb. 2).

- Prüfen Sie, bevor Sie das Gerät in Betrieb nehmen, ob die Spannungsangabe auf dem Gerät mit der örtlichen Netzspannung übereinstimmt.

- Verwenden Sie das Gerät nicht, wenn der Netzstecker, das Netzkabel oder das Gerät selbst defekt oder beschädigt ist.

- Es kann nur das von Philips bereitgestellte Kabel verwendet werden.

- Vergewissern Sie sich, dass Ihre Hände trocken sind, wenn Sie das Netzkabel am Gerät und an der Steckdose anschließen.

- Dieses Gerät sollte nicht von Kindern verwendet werden. Halten Sie das Gerät und das Netzkabel außerhalb der Reichweite von Kindern.

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Dieses Gerät kann von Personen mit verringerten physischen, sensorischen oder psychischen Fähigkeiten oder Mangel an

- Erfahrung und Kenntnis verwendet werden, wenn sie bei der Verwendung beaufsichtigt wurden oder Anweisung zum sicheren Gebrauch des Geräts erhalten und die Gefahren verstanden haben.

- Achten Sie darauf, dass Kinder nicht mit dem Gerät spielen.

- Verwenden Sie keine aggressiven Reinigungsmittel, um die Oberflächen zu reinigen, die in Kontakt mit Lebensmitteln kommen.

- Vorsicht**
- Dieses Gerät ist nur für den Gebrauch im Haushalt bestimmt. Bei unsachgemäßem Gebrauch oder Verwendung für halbprofessionelle oder professionelle Zwecke oder bei Nichtbeachtung der Anweisungen in der Bedienungsanleitung besteht Verletzungsgefahr, und die Garantie erlischt. In diesem Fall lehnt Philips jegliche Haftung für entstandene Schäden ab.

- Stellen Sie das Gerät auf eine trockene, stabile und ebene Fläche.

- Schließen Sie das Gerät nur an eine geerdete Steckdose an.

- Verwenden Sie niemals Zubehör oder Teile, die von Drittherstellern stammen bzw. nicht von Philips empfohlen werden. Wenn Sie diese(s) Zubehör oder Teile verwenden, erlischt Ihre Garantie.

- Dieses Gerät ist nicht dafür geeignet, über einen externen Timer oder ein separates Fernbedienungssystem gesteuert zu werden.

- Trennen Sie das Gerät immer von der Stromversorgung, wenn Sie es unbeaufsichtigt lassen und bevor Sie es zusammensetzen, auseinandernehmen oder reinigen.

- Lassen Sie das eingeschaltete Gerät nicht unbeaufsichtigt.

- Lassen Sie das Gerät nicht ohne Pause laufen.

- Schalten Sie das Gerät nicht ein, wenn es leer ist.

- Fügen Sie nie Inhalt (einschließlich Flüssigkeiten) ein, wenn dieser die MAX- oder MIN-Markierung am Gerät über- bzw. unterschreitet.

- Achten Sie auf heißen Dampf, der während der Verarbeitung an der Kante des Deckels austreten kann, sowie auf heißen Dampf, der aus dem Gerät austreten kann, wenn Sie die Motoreinheit nach Zubereitung einer heißen Suppe entfernen.

- Berühren Sie die Messer nicht. Die Messer sind sehr scharf.

- Heben Sie während des Betriebs die Motoreinheit nicht an und bewegen Sie das Gerät nicht.

- Dieses Gerät ist nicht für gefrorene Zutaten geeignet.

- Tauen Sie die Zutaten immer auf, bevor Sie sie in die Kanne geben.

- Dieses Gerät eignet sich nicht zum Erhitzen von Milch.

- Halten Sie das Gerät immer am Griff an der Kanne. Halten Sie das Gerät nicht am Handgrip auf der Motoreinheit, da es überkippen kann. (Abb. 3)

- Halten Sie das Gerät immer am Griff an der Kanne. Halten Sie das Gerät nicht am Handgrip auf der Motoreinheit, da es überkippen kann. (Abb. 3)

- Halten Sie das Gerät immer am Griff an der Kanne. Halten Sie das Gerät nicht am Hand

