




M9990117
03/23-C021-R01

GhostSlim^{PLUS} T600



IT	ISTRUZIONI DI MONTAGGIO
FR	INSTRUCTIONS DE MONTAGE
EN	MOUNTING INSTRUCTIONS
DE	MONTAGEANLEITUNG
NL	MONTAGEVOORSCHRIFT
ES	GUÍA DE MONTAJE
PT	INSTRUÇÕES DE MONTAGEM
PL	INSTRUKCJA MONTAŻU
CZ	NÁVOD K MONTÁŽI
RO	INSTRUCȚIUNI DE MONTARE
HU	SZERELÉSI ÚTMUTATÓ
FI	ASENNUSOHJEET
SK	NÁVOD NA MONTÁŽ
SL	NAVODILA ZA MONTAŽO
MK	ИНСТРУКЦИИ ЗА МОНТАЖА
SQ	UDHËZIME PËR MONTIMIN

