

GB
Instructions for using the stainless-steel MOBILITY SLIM drinking flask.

Congratulations!
You have chosen a top-quality product from the house of EMSA. Please read the instructions through carefully to ensure you use this superior product to its best advantage and it will give you years of good service. Please follow all the hints on safety and care of your MOBILITY SLIM and retain these instructions for future reference. If this product is intended for another person, please be sure to pass on these instructions for use together with the flask.

- Hints on safety
- Never hold your face directly over the opening when filling the flask.
 - Please take care not to scald your mouth when drinking hot beverages from your MOBILITY SLIM.
 - Never place your MOBILITY SLIM on a hotplate which is still hot or warm, or in the microwave or the oven (risk of damage to the plastic parts).
 - Never fill your MOBILITY SLIM with carbonated drinks or dry ice.
 - Vacuumware must not be used for keeping milk products (risk of bacterial contamination).
 - Keep the MOBILITY SLIM out of the reach of young children (risk of scalding).
 - CAUTION! Please drink hot beverages with care – danger of scalding.
 - Keep the plastic packaging and bag out of the reach of babies and young children (risk of suffocation).

- Care of your MOBILITY SLIM
- Wash your MOBILITY SLIM with hot water and washing-up liquid before using for the first time and when it has not been in use for a while. Rinse with clear water.
 - To make sure hot beverages retain the heat longer, rinse out your MOBILITY SLIM with hot water before filling it with the hot drink. Cold drinks stay cool longer if you rinse out the flask with cold water or place it open in the refrigerator before filling.
 - You can boost the cooling properties of your MOBILITY SLIM by adding ice cubes.
 - We recommend warming or cooling the flask for at least three minutes prior to use.
 - You can achieve the best vacuum performance from your MOBILITY SLIM by filling it to the line beneath the opening.

- Cleaning
- Rinse your MOBILITY SLIM with hot water after every use.
 - Your MOBILITY SLIM is NOT dishwasher-safe!
 - The closure comes apart for optimum hygiene.

- Tips for washing by hand:
 - Inside: Stubborn stains can be removed from the inside of the flask using dishwasher detergent. Fill the flask with hot water, add about 1 dessert spoonful of dishwasher or baking powder and allow to stand. Rinse well with clear water.
 - Outside: Just use a soft, moistened cloth to clean the outside by hand without detergents.
 - Limescale build-up can be removed with the help of a hot vinegar solution.
 - Please use soft brushes only to remove any obstinate residue.
 - Hard, sharp-edged brushes and coarse or abrasive cleansers may scratch the stainless-steel and plastic surfaces.
 - Do not use scouring agents, solvents or bleach of any kind.
 - Leave your MOBILITY SLIM open while it dries.

Storage
Always put your MOBILITY SLIM away with the lid off to avoid the build-up of bacteria or unpleasant odours.

Guarantee
This product carries a 5-year guarantee. The guarantee covers manufacturing and material defects provided the flask has not been misused. In the event of a claim, please contact the service department at the following address.

EMSA GmbH · Grevener Damn 215-225 · 48282 Emsdetten Germany

INSTRUCTIONS MOBILITY SLIM



CN
不锈钢饮料杯 MOBILITY SLIM 使用说明

衷心祝贺！
您购买的饮料杯是 EMSA 公司生产的高品质产品。为了使您购买的优质产品得到最佳的使用而给您带来长久的乐趣，请您仔细阅读本使用说明书。请您遵照说明书中的所有安全提示和使用提示，并妥善地保管本使用说明书，以备日后查阅。如果您将本产品转让给他人，请将本使用说明书一并转让。

- 安全提示
- 在向饮料杯加注饮料时，不要将脸部靠近杯口。
 - 在饮用 MOBILITY SLIM 饮料杯中的热饮时要小心（以防造成烫伤）。
 - 绝不要将 MOBILITY SLIM 饮料杯放置到热炉板上，微波炉或者烤箱中（否则会有导致塑料件损害的危险）。
 - 不要向饮料杯中加注含碳酸的饮料或者干冰。
 - 原则上，保温容器不适用于作对奶制品的保温（有产生细菌的危险）。
 - 不要让幼儿接触到 MOBILITY SLIM 饮料杯（以防造成烫伤）。
 - 不要让婴幼儿接触到包装袋和包装薄膜（有造成婴幼儿发生窒息的危险）。
- 警告！如果饮料过热，请小心使用，可能会造成烫伤

- 使用
- 在第一次使用或者较长时间没有使用 MOBILITY SLIM 饮料杯之后重新使用前，要先用热水和洗洁剂洗涤饮料杯。然后用冷水冲洗。
 - 为了可以使得热饮在 MOBILITY SLIM 较长时间地保温，可以先用热水涮一下保温杯，然后装入饮料。在装入冷饮之前，如果将饮料杯用冷水涮一下，或者事先将饮料杯敞开放在冰箱中然后装入冷饮，可以较长时间地是冷饮保冷。
 - 在饮料杯中放入冰块可以提高您的 MOBILITY SLIM 的保冷能力。
 - 我们建议对饮料杯至少预热或者预冷三分钟。
 - 在 MOBILITY SLIM 饮料杯中加注饮料需在杯口下留有少量空气，饮料杯的绝热效果最佳。

- 清洁
- 在每次使用 MOBILITY SLIM 饮料杯之后，要用热水冲洗饮料杯。
 - 彩色烤漆的 MOBILITY SLIM 不适于洗碗机内清洗（有磨损漆面的可能）
 - 清洗时，将饮料杯的盖子拆分为两个部分可以获得最佳的清洁效果。

- 关于手洗饮料杯的说明：
- 内部：用洗碗机洗碗粉可以去掉沉积在饮料杯内部难以取出的沉积物。为此，可以向饮料杯中加入热水，然后加入一食匙洗碗机洗碗粉或者焙粉，并等其作用一段时间。
 - 接着用冷水将饮料杯冲洗干净。
 - 外部，请只使用质地柔软的湿布擦拭饮料杯
 - 钙沉积可以使用热醋水去除。
 - 清除杯中的固体残余物时，请只使用质地柔软的刷子。
 - 坚硬、锐利的刷子以及粗粒或者磨蚀性清洁剂会造成不锈钢和塑料表面出现划痕。
 - 请不要使用磨擦剂、溶剂或者漂白剂。
 - 清洁后要让 MOBILITY SLIM 饮料杯敞开干燥。

存放
存放 MOBILITY SLIM 饮料杯时，要将其盖子敞开，以防产生细菌或者出现异味。

质量保证
本产品的质量保证为 5 年。在使用适当的情况下，用户在为期 5 年的质量保证期内可因饮料杯的生产缺陷或者材料缺陷要求质量保证。要求质量保证时，请您联系购买时的 EMSA 专柜或和以下地址联系。

EMSA GmbH 有限公司 · Grevener Damn 215-225 · 48282 Emsdetten, 德国

EMSA GmbH
48282 Emsdetten
Germany
www.emsa.com



10.13

Id.- Nr. 36674