




Bissell®

SPOTCLEAN PRO ADVANCED

1558D

EN	USER GUIDE	KO	사용 설명서
AR	مدىخستسمل ال يلد	LT	NAUDOTOJO VADOVE
BG	РЪКОВОДСТВО ЗА ПОТРЕБИТЕЛЯ	LV	LIETOTĀJA ROKASGRĀMATĀ
BS	KORISNIČKOM PRIRUČNIKU	MK	УПАТСТВО ЗА УПОТРЕБА
CHS	使用手册	ML	PANDUAN PENGGUNA
CHT	使用指南	NL	GEbruikersHANDLEIDING
CZ	UŽIVATELSKÁ PŘÍRUČKA	NO	BRUKERVEILEDNING
DE	BENUTZERHANDBUCH	PL	INSTRUKCJA OBSŁUGI
DK	BRUGERVEJLEDNING	PT	MANUAL DE UTILIZAÇÃO
EL	ΟΔΗΓΟ ΧΡΗΣΗΣ	RO	GHID DE UTILIZARE
ES	GUÍA DEL USUARIO	RU	РУКОВОДСТВО ПОЛЬЗОВАТЕЛЯ
ET	JUHENDIS	SE	ANVÄNDARHANDBOK
FI	KÄYTTÖOPAS	SK	POUŽÍVATELSKÁ PRÍRUČKA
FR	MANUEL DE L'UTILISATEUR	SL	UPORABNIŠKEM PRIROČNIKU
HR	KORISNIČKI VODIČ	SR	KORISNIČKOM UPUTSTVU
HE	מתמל מידוד	TA	பயனரின கயைடே
HU	HASZNÁLATI ÚTMUTATÓ	TH	คู่มือใช้
IT	GUIDA PER L'UTENTE	TR	KULLANICI KILAVUZU





..... 3



..... 4



..... 5









..... 6
















..... 8



..... 9







Wash & Protect Pro

