

**Rakutenkobo**

Kobo Stylus 2  
User Guide

## TABLE OF CONTENTS

|   |   |
|---|---|
| Using your Kobo Stylus 2.....                     | 3 |
| Features .....                                    | 3 |
| Using your Kobo Stylus 2 for the first time ..... | 4 |
| Charge your Kobo Stylus 2.....                    | 5 |
| Using Kobo Stylus 2 .....                         | 6 |
| Stylus Specifications .....                       | 7 |
| Need help?.....                                   | 8 |
| Safety, Regulatory and Warranty Information.....  | 8 |

# Using your Kobo Stylus 2

## Features

---

Your Kobo Stylus 2 lets you write and draw on some Kobo eReaders. It features a built-in eraser, pressure sensitive writing tip, and a built-in battery.



- **(1) Pressure sensitive tip:** Write thick and thin lines, just like a real pen. Apply more pressure to create darker lines. Apply thin pressure to create light lines.
- **(2) Highlight button:** Press and hold to highlight a passage of text.
- **(3) Charging port (USB-C):** Connect a USB-C cable to your Kobo Stylus to charge it. It can take up to an hour or more to fully charge your Kobo Stylus.
- **(4) Battery indicator (LED):** Flashes orange when the battery needs to be charged.
- **(5) Eraser:** Use the eraser to delete text or lines in while drawing or writing.

## Using your Kobo Stylus 2 for the first time

---

Before you use your Kobo Stylus 2 for the first time:

- Connect one end of the USB-C cable to your stylus and the other end to your computer or USB outlet to activate your stylus.
- Fully charge your stylus

## Charge your Kobo Stylus 2

---

Your Kobo Stylus 2 has a built-in battery that charges with a USB-C cable.

Your Kobo Stylus 2 turns off automatically after five minutes of inactivity to conserve battery life. The stylus will wake up once you start writing.

- When the battery is low, the LED indicator flashes orange
- If the battery goes down to zero, the LED indicator will stop flashing

To charge your Kobo Stylus 2:

1. Connect your USB-C cable to the charging port on your Kobo Stylus.
2. Connect the other end of the USB-C cable to your computer or USB-C wall charger.

### **Battery life indicators**

Your Kobo Stylus has a LED light next to the USB-C charger. Depending on how much battery is remaining, the LED light flashes different colours.

- **Battery low:** Flashes orange
- **Battery charging:** Static orange
- **Fully charged:** Static white

To check your Kobo Stylus 2 battery life on your eReader, tap the battery icon in the Home screen.

## Using Kobo Stylus 2

---

Kobo eReader features a Journal feature that lets you write and draw on your Kobo eReader.

To use the Journal feature:

1. Go to your Home screen.
2. Tap My Notebooks at the bottom of the screen.
3. Tap New to create a new journal.
4. Follow the onscreen steps to choose a basic or advanced journal.

# Stylus Specifications

- Battery capacity: 3.7V 65mAh
- Charging port: USB Type-C
- Charging voltage: 5V
- Operating temperature: 0°C ~ 40°C

## Need help?

To get help and learn more about your eReader and other Rakuten Kobo products, visit:

<https://help.kobo.com>

## Safety, Regulatory and Warranty Information

---

Important safety, regulatory and warranty details about your Kobo eReader can be found on the Kobo website at:

- <https://help.kobo.com>
- [www.kobo.com/userguides](http://www.kobo.com/userguides)

**Note:** The Declaration of Conformity may vary for different models of the Kobo eReader. The web site includes details of how to find your Kobo eReader model number.