

## KEEP THESE IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions before using this appliance.

This appliance is intended for household use only.



**WARNING:** Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

**WARNING:** When the hairdryer is used in a bathroom, unplug it after use since the proximity to water presents a hazard even when the hairdryer is switched OFF.

For additional protection the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.

This appliance can be used by children aged from 8 years and above, and by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children shall not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

**WARNING:** Do not leave the appliance unattended. Do not allow bare skin or the eyes to come into contact with any heated surface on the appliance when in use. Do not place the appliance on any heat-sensitive surfaces when hot or plugged into the mains. Always unplug the appliance when not in use.

**WARNING:** Do not block the air inlet or outlet during use. When using the appliance, care must be taken to prevent hair entering the air inlet opening. The air outlet opening of this appliance will become hot during use, avoid touching the outlet or any accessories attached to the outlet.

**WARNING:** Do not use this appliance on synthetic hair or wigs.

NOTE: Use on towel dried hair only.

**WARNING:** Should this product malfunction, do not attempt to repair it.

This appliance has no user-serviceable parts or components.

**WARNING:** Do not touch the cool tip when in use as it may be hot.

### Guarantee and Service section:

Your REVLON appliance is guaranteed against defects under normal use for 4 years from the original date of purchase. If your product does not perform satisfactorily because of defects in materials or manufacture, within the guarantee period, it will be replaced.

Please retain your till receipt or other proof of purchase for all claims within the guarantee period. The guarantee becomes void if the proof of purchase is not presented. Simply take the appliance back to the retailer from where purchased, along with a valid till receipt, for exchange free of charge. This guarantee does not cover defects which have occurred due to misuse, abuse or are caused by failure to follow the instructions contained within this manual.

UK only: This does not affect your consumer statutory rights.

The manufacturing date is given by the 4 digit Batch Number marked on the rear of the product. The first 2 digits represent the week of manufacture, and the last 2 digits represent the year of manufacture. Example: 3423 - product manufactured week 34 of the year 2023.

The appearance of this appliance may differ from the illustration.

For product support, please visit us at: [www.HelenofTroy.com/emea-en/support](http://www.HelenofTroy.com/emea-en/support) or write to [Revlon\\_Support@helenofTroy.eu](mailto:Revlon_Support@helenofTroy.eu) or contact us by phone: +44 (0) 207 949 0115

For product information, visit us at: [www.revlonhairtools.shop](http://www.revlonhairtools.shop)

These instructions are also available on our website.

Please visit [www.HelenofTroy.com/emea-en/Support](http://www.HelenofTroy.com/emea-en/Support)



This appliance complies with EU legislation 2012/19/EU on end of life recycling. Products showing the 'Crossed Through' wheeled bin symbol on either the rating label, gift box or instructions must be recycled separately from household waste at the end of their useful life.

Please DO NOT dispose of appliance in normal household waste. Your local appliance retailer may operate a 'take-back' scheme when you are ready to purchase a replacement product, alternatively contact your local government authority for further help and advice on where to take your appliance for recycling.

This product carries the CE mark and is manufactured in conformity with the Electromagnetic Directive 2014/30/EU, the Low Voltage Directive 2014/35/EU, the ERP Directive 2009/125/EC, and the ROHS Directive 2011/65/EU.

## REVLON®

220-240V - 50-60Hz 1000W

Type#, EH5330FD

The REVLO<sup>®</sup> trademark is used under licence from Revlon by Helen of Troy Limited.



Kaz Europe Sàrl  
Q-Center, Chaux 4  
CH-1030 Bussigny - Switzerland



Made and printed in China

# REVLON®



## ONE STEP™ **AIR STRAIGHT** 2-IN-1 DRYER & STRAIGHTENER

RVDR5330UK

## OPERATING INSTRUCTIONS

This appliance is intended for household use only.  
The appearance of this appliance may differ from the illustration.  
Only use this appliance for its intended purpose, as described in this manual.

## AIRPAUSE™ TECHNOLOGY

Airflow is activated when plates are closed, it pauses when handles are released.

## CERAMIC TOURMALINE PLATES INFUSED WITH ARGAN OIL

Help increase shine and reduce damage from overstyling with even heat distribution.

## OVERHEATING CUT-OFF

This appliance is equipped with a thermostat that will cycle OFF should the heat of the dryer exceed the optimum drying level, due to partially blocked air inlet or outlet openings.  
In the event that the appliance stops or releases only cool air during use, turn the appliance OFF and allow it to cool down. Once the appliance cools, the thermostat will automatically reset and usage may resume.

## DAMP HAIR SETTINGS

Use Cool, Low, Medium or High Air to dry hair.

## DRY HAIR SETTINGS

Use Hot Air & Heated Plates or Heated Plates only to style dry hair.

**DO NOT** use dry hair settings on wet or damp hair.

## HOW TO OPERATE THE ONE-STEP™ AIR STRAIGHT

- Plug the appliance into the mains socket.
- To unlock and turn the appliance on, rotate the control dial clockwise, to the right.
- To dry, start with the Low Air (2.) setting, then adjust to Medium Air (3.) or High Air (4.), as desired. AIRFLOW WILL NOT BEGIN UNTIL YOU ACTIVATE IT BY PRESSING THE HANDLES TOGETHER.
- To straighten & finish the look, adjust setting to Hot Air & Heated Plates (5.) or Heated Plates (6.) only. ONLY USE DRY HAIR SETTINGS ON DRY HAIR.
- Lock in the look by using the cold button (1.).
- To turn the appliance off, rotate the control dial counterclockwise, to the left.

## STYLING TIPS

- Towel or air-dry hair until it's just damp, then run a comb through to detangle.
- Separate hair into manageable sections.
- With the air vent side on top, squeeze handles together to clamp hair and slowly activate airflow.
- Slowly slide appliance to the ends. Repeat until hair is fully dry.
- Smooth and finish by rotating the control setting to Hot Air & Heated Plates (5.) or Heated Plates (6.) ONLY.
- The heated plates indicator lights will glow when the plates are ready to use.
- Separate hair into manageable sections.
- Clamp hair firmly, slide the appliance to ends. Repeat until desired look is achieved.
- Allow hair to cool before combing or brushing.

## CLEANING

Routine cleaning is highly recommended. Always unplug the appliance from the mains after use and allow it to cool before cleaning. To clean, wipe the appliance with a damp cloth. Dust and lint can be removed from the air intake openings with a small brush or vacuum cleaner with a brush attachment. Make certain the appliance is completely dry before using. Keep heated surfaces clean and free of dust, dirt, styling sprays and gels.

**DO NOT** allow moisture or additional debris to enter the unit while cleaning.

## STORAGE









Always unplug when not in use.

Allow the appliance to cool before storing. Always store in a dry location. Do not pull or twist the cord. Do not wrap the cord around the appliance, as this may cause the cord to wear prematurely and break. Regularly check the power cord for wear and damage (particularly where it enters the appliance and the plug).

## FEATURES

- A. Ceramic Tourmaline plates & teeth, infused with Argan Oil
- B. Airflow vents
- C. AirPause™ Technology
- D. Heated plate indicator lights
- E. Air inlets
- F. 6 settings & control dial
- G. 2.5m swivel cord
- H. Glove



6 SETTINGS	
DAMP HAIR SETTINGS	DRY HAIR SETTINGS
 (1.)	 (5.)
 (2.)	 (6.)
 (3.)	
 (4.)	
 THESE SETTINGS MUST BE USED ON DRY HAIR ONLY 	


# Helen of Troy

Start Date 26SEP23  
Model# **RVDR5330UK**  
UK/E UK  
Agile AW# AW016829  
AW Issue# No#: 2 Date 11OCT23  
Languages English  
File Name rvdrib.RVDR5330UK.AW016829.INDD  
Designer Simon Finch  
Factory FENDA  
Bar Code# n/a

## Packaging Specifications

Dimensions H185 x W89 mm Finished size  
Material 70gsm wood free paper  
Finishes Roll fold  
Colours Black

This proof is  
not intended  
for colour  
matching  
but for colour  
indication



## Proof Stages

27SEP23 Created artwork based on N1 version  
28SEP23 Amends  
02OCT23 Amends  
04OCT23 Amends in-line with packaging  
05OCT23 Amends  
05OCT23 Uploaded for production  
11OCT23 Changed name to AIR STRAIGHT  
12OCT23 Reuploaded for production

## Approvals

BM/MKT 11OCT23 Camille Bosson  
BM/MKT 11OCT23 Simona Tomassini  
MKT MNG --- ---  
Design 12OCT23 Loc Pham  
Eng. UK/E 27SEP23 James Briscoe  
Comp. UK/E 27SEP23 Seray Sahin  
Eng. APO 27SEP23 N. Han / N. Zhong / J.Zhang  
Compl. APO 27SEP23 John Guo  
Legal --- ---  
Licensor --- ---

## Helen of Troy - Kaz Europe Sàrl

Creative Department  
Route de la Chaux 4  
CH-1030 Bussigny - Switzerland