



COMMAND SERIES KB5 – QSG



PACKAGE CONTENTS

1. Turtle Beach® Command Series KB5
2. USB-C to USB-A Cable
3. Detachable Wrist Rest
4. Additional WASD Textured Keycaps
5. Keycap Puller


SETUP



USB-A connection


1. For a more ergonomic position, fold out the stands on the base of the keyboard and install the palm rest by inserting it into the front palm rest port. **ATTENTION:** Make sure the palm rest is fully inserted into the keyboard for the best fit.
2. Connect the USB-A cable directly to the USB-A port of your PC.
 - a. **ATTENTION:** do not use a USB hub, the power output might not be enough to power the keyboard resulting on screen, RGB or input malfunction.
3. Connect the USB-C cable to the Keyboard.

Driver installation




1. Navigate to www.turtlebeach.com/swarm2 and download the latest driver software.
2. Complete the installation to get access to all display, software features and setup.

KEYBOARD CONNECTIVITY



1. USB-C Power port

VOLUME BARREL DEFAULT BINDINGS



ITEM	DEFAULT BINDING
1	• Barrel roll forward = Volume up • Barrel roll backward = Volume down • Barrel click – Volume mute

ADDITIONAL FN FUNCTIONALITY



STANDARD

SHORTCUT	BINDINGS
FN+F1	Profile 1
FN+F2	Profile 2
FN+F3	Profile 3
FN+F4	Profile 4
FN+F5	Open SWARM II
FN+F6	Open My PC
FN+F7	Snapshot
FN+F8	Trigger record macro

MEDIA KEYS

SHORTCUT	BINDINGS
FN+F9	Previous track
FN+F10	Stop
FN+F11	Play/Pause
FN+F12	Next track

LED CONTROL KEYS

FN + SHORTCUT	BINDINGS
FN + CURSOR LEFT	Previous RGB effect
FN + CURSUR RIGHT	Next RGB effect
FN + CURSOR DOWN	RGB brightness down
FN + CURSOR UP	RGB brightness up
FN + ALT right	Color Cycle
FN + CTRL right	RGB on/off

GAME MODE

SHORTCUT	BINDINGS
FN+WIN	Toggle Game mode
FN + Caps Lock	Toggle Easy-Shift [+] TM


AI

SHORTCUT	BINDINGS
FN + MENU	Copilot shortcut

COMMAND DISPLAY LINE ART OF SCREEN UI

Located above the numpad, the 2.4" Command Touch Display combines keyboard inputs, hotkeys, app launching and advanced functions such as multimedia controls and 3rd party software integration. Each of the 5 on-board profiles has 3 dedicated pages, each with up to 6 virtual buttons, for a total of 18 customizable inputs. It also includes a volume management page and a setting menu for control settings on-the-fly.

ATTENTION: Some of the widgets will be available only after SWARM II Software installation and to work properly they will need the software to be open in the background and connected. Images for explanation purpose only, actual screen appearance might differ from imagery according to feature availability or firmware version.




1. Tap to home page button to quick access home page
2. Widget area grid
3. Swarm II connection sync status
 - a. Connected
 - b. Disconnected
4. Keyboard status indicators:
 - Caps lock
 - Num lock
 - Scroll Lock

5. Layer indicators:
 - FN
 - Game mode
 - Easy-shift
6. Tap to cycle across profile 1 to 5
7. Tap setting menu button to access on-board setting pages
8. Breadcrumbs page navigation pattern

COMMAND DISPLAY SETTING CLIP ART OF SCREEN UI

ATTENTION: Tapping the settings menu button will reveal an overlay screen. Here you can view and adjust the performance of the product on-the-fly.




- 9. Display brightness slider
- 10. Keyboard RGB brightness slider
- 11. Breadcrumbs setting navigation pattern
- 12. Wireless device battery status

ATTENTION: Only works with other Turtle Beach compatible devices, when connected to Swarm II.

- 13. Setting widget area, tap to access each dedicated-on board setting page such as react tap, macro recording, hotkey assignment and more.
- 14. Firmware version

COMMAND DISPLAY AUDIO MIXER CLIP ART OF SCREEN UI

ATTENTION: The Audio mixer will work only after SWARM II Software installation and to work properly the software needs to be open in the background and connected. Images for explanation purpose only, actual screen appearance might differ from imagery according to feature availability or firmware version.




15. System volume slider

16. Windows volume mixer channel's sliders.

COMMAND DISPLAY NAVIGATION INSTRUCTIONS

- By default, the first page on the display is P1 the HOME and main page: you can always return to the HOME page and quickly access it by tapping the HOME PAGE BUTTON [1].
- To navigate the Command Touch Display pages VM, P1 -3 you can swipe left or right. Breadcrumbs patterns [8] will show your current location on the widget page VM, P1 – 3 and setting pages S1-3.
- To access the on-board setting menu, press SETTING PAGE BUTTON [7]; to exit the setting menu or a setting widget tap on HOME PAGE BUTTON [8].



VM – Volume Mixer Page

P1 – Widget Page 1 (Home)

P2 – Widget Page 2

P3 – Widget Page 3

S1 – Setting Page 1

S2 – Setting Page 2

S2 – Setting Page 3

TECHNICAL SPECIFICATIONS

- **Form Factor:** Full-Sized [Extended]
- **Connectivity:** USB-A Wired
- **Cable:** 1.8m / 5.9ft Detachable USB-A
- **Lighting:** Per-Key RGB Illumination
- **Switches:** Low-Profile Mechanical Linear
- **Travel Distance:** 3.1mm
- **Actuation Point & Force:** 1.2mm & 42gf
- **Switch Lifecycle:** 50M Keystrokes
- **Processor:** 32-bit ARM
- **Screen:** 2.4" Full Color Touch Display
- **Polling Rate:** 8000 Hz
- **Adjustable Height:** Double Kickstand
- **Keyboard Rollover:** Full Key, Anti-Ghosting
- **On-Board Memory:** 32MB
- **Software:** Swarm™ II
- **Product Weight:** 887 g / 1.96 lb // 1100 g / 2.43 lb [with palm rest]
- **Product Dimensions:** 477 mm X 257 mm X 27 mm / 18.78 in X 6.89 in X 1.06 in [with palm rest]

SYSTEM REQUIREMENTS

- Windows 10 and above [software support]
- Direct PC connection USB-A 2.0 (or higher). **USB hubs not supported.**
- Internet Connection [for driver software]