

QUICK START GUIDE

PARTYBOX ENCORE2



HARMAN




WHAT'S IN THE BOX



*Power cord quantity and plug type vary by regions.

**The quantity of microphones and microphone holders varies by regions.

BLUETOOTH PAIRING



PLAY




LIGHTSHOW



Apply lightshow presets and more with the JBL PARTYBOX app.

APP



Download and install the JBL PARTYBOX app to get more from the product.





JBL PARTYBOX


GET IT ON Google Play

Download on the App Store

MICROPHONE



GUITAR




MULTI-SPEAKER CONNECTION



CHARGING




MICROPHONE HOLDER




BATTERY REPLACEMENT

1 Remove the Old Battery



2 Insert the New Battery



Change the battery before first use.

