



NOTICE DE MONTAGE

CPX 60 & 75




1




x2

Outils non fournis/Tools not provided/Nicht gefnerlierte Werkzeuge


T1





T30




10 mm



x2





1



x2

T1



ATTENTION

Ne pas fermer le couvercle lorsqu'un brûleur est allumé.

WARNING

Never close the lid when a burner is on.

ACHTUNG

Deckel nicht schliessen, wenn ein Brenner angezündet ist.