



Moniteur PC / PC monitor


EB_E15-34-C



Aide à la réparation / After-sales solutions

8009217

Vue éclatée / Exploded view



Liste des pièces détachées / Spare parts list

N° VUE	REF PIECE	DESIGNATION (FR)	DESIGNATION (ENG)
1	9013642	DALLE LCD LOT 21_33_1900581	LCM (Optical+OC+T-con)
1	9016758	DALLE LCD LOT 21-42-1900581	LCM (Optical+OC+T-con)
3	9013637	CARTE MERE LOT 21-33-1900581	MAIN BOARD
3	9016653	CARTE MERE LOT 21-42-1900581	MAIN BOARD
4	9013693	BORNIER	TERMINAL BLOCK
7	9013638	CARTE ALIMENTATION	POWER BOARD AY078D-1SF30
9	9013639	COQUE ARRIERE	BACK COVER
12	9013702	BROCHE	SPINDLE PART
13	9015537	CACHE (COQUE ARRIERE)	REAR SHELL DECORATIVE COVER
14	9013640	PIED	ADJUSTABLE STAND
15	9013641	BASE (PIED)	STAND BOTTOM BASE
19	9013692	CARTE (TOUCHES)	KEY BOARD
	9013694	CABLE (DALLE)	CABLE (PANEL)
	9013695	CABLE (PRISE ALIM / CARTE ALIM)	CONNECTING WIRE (POWER SOCKET AND POWER BOARD)
	9013696	CABLE (CARTE BOUTON)	CONNECTING WIRE (KEY BOARD)
	9013697	CABLE (CARTE ALIM / CARTE MERE)	CONNECTING WIRE (POWER BOARD AND MAIN BOARD)
	9013698	CABLE (T-CON)	CONNECTING WIRE (T-CON)
	9013699	CABLE ALIMENTATION	POWER CABLE
	9013700	BANDE LED GAUCHE	LEFT LED LIGHT STRIP
	9013701	BANDE LED DROITE	RIGHT LED LIGHT STRIP
	9013643	VIS VESA (PIED)	SCREWS