


ASSEMBLY INSTRUCTION



AX1		Ix3	 M6x35mm
BX1		Jx4	 M8x35mm
CX1		Kx1	
DX1(L)X(R)		Lx1	
Ex1		Mx1	
FX1		Nx1	
GX5		Ox2	
Hx4	 M6x20mm	Qx1	