

SAINT ALGUE 

Demeliss<sup>®</sup> One



EN

MODEL SA-191

## WARNINGS

WARNING: Do not use this appliance near bathtubs, showers, basins or other vessels containing water.



This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

When using the appliance in a bathroom, unplug it after use, because its proximity to water can present a danger even when the appliance is switched off.

For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30mA is advisable in the electric circuit supplying the bathroom. Ask your installer for advice.

If the supply cord is damaged, it must

be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

### BEFORE USING THE DEVICE

- Remove all packaging.
- Clean the device using a slightly damp cloth. Dry the device.
- Fully uncoil the power cable.

### INSTRUCTIONS FOR USE

- Before using the device, make sure your hair is clean and tangle-free.
- Plug-in the device.
- To turn on the device, press the ON/OFF button for 3 seconds. A long beep sound will indicate the device is ON.
- Once the device is ON, the plates temperature will instantly start increasing until reaching the 200°C temperature.
- During heating-up phase, the LED indicator around the ON/OFF button will start flashing. Once the maximum temperature is reached, two beep sounds will indicate that the device is ready for use, and the LED indicator will stop flashing and stay on.

The approximate heating time is between 9 seconds and 11 seconds.

- Once straightening is over, to turn off the device press the ON/OFF button for 3 seconds, then unplug it. Leave for a few minutes for cooling.
- The device has a safety automatic shut-off function. The device will turn off automatically after one hour.

### CLEANING

Switch-off and unplug the device, then allow it to cool.

Remove any hair that may have been left on the device.

Clean the device using a slightly damp cloth and then dry it.

**WARNING!** Do not immerse the device and/or its power cable in liquid: risk of short-circuit or electric shocks.



This symbol, displayed on the product or on its packaging, indicates that this product complies with the European Directive 2012/19/EU and must not be disposed of with household waste.

It must be taken to an appropriate collection point for recycling electrical and electronic equipment.

By ensuring that this product is disposed of in an appropriate way, you will be helping to prevent potential harmful consequences for the environment and human health.

Recycling materials will help to conserve natural resources.