Getting Started - MK295 Silent Wireless Combo



Product Overview





Mouse

- 1. Left/right-click button
- 2. Scroll wheel/middle-click button
- 3. On/Off
- 4. Battery door

Keyboard

- 1. Media hotkeys
- 2. Caps lock indicator
- 3. On/Off
- 4. Battery door
- 5. USB storage
- 6. 8-degree tilt leg

Receiver

1. USB receiver

NOTE: Removing and reinstalling the keycaps will impact the noise reduction performance.

SilentTouch keys and media hotkeys



- 1. Play/Pause
- 2. Mute volume
- 3. Decrease volume
- 4. Increase volume
- 5. Navigate to the internet home
- 6. Launch email application
- 7. Place computer in standby mode
- 8. Launch calculator
- 9. SilentTouch Keys

Tilt legs

Choose from natural tilt or 8-degrees tilt positions based on your typing preference.

Natural tilt

8-degree tilt

