

SET UP

DOWNLOAD THE BANG & OLUFSEN APP

To set up your product, download the Bang & Olufsen App from the Google Play Store or Apple App Store.

From this app you can set up and get the most out of your Beosound Stage.

When you first start the Bang & Olufsen App, you will be asked to create a user account.

To set up your speaker, click to add a new product. If you already have an account this can be found under settings.



BANG & OLUFSEN APP

