

ES. Para resolver cualquier duda, visita: help.onspc.com

EN. To resolve any queries, visit: help.onspc.com

PT. Para resolver qualquer dúvida, visite: help.onspc.com


FR. Pour résoudre tout doute, visitez: help.onspc.com

DE. Um Fragen zu beantworten, besuchen Sie: help.onspc.com

IT. Per risolvere qualsiasi dubbio, visita: help.onspc.com


TR. Şüphelerinize gereken cevapları help.onspc.com web sayfamızda bulabilirsiniz.

PL. Aby odpowiedzieć na wszelkie pytania, proszę odwiedzić stronę: help.onspc.com



CARGA RÁPIDA
FAST CHARGE
CHARGE RAPIDE


! NOT INCLUDED



SINGLE TAP
OPEN APP



LONG PRESS
SELECT



MANTÉN PRESIONADO PARA SELECCIONAR LA APP

Una vez seleccionada la app, con un toque se abrirá la app previamente seleccionada.

LONG PRESS TO SELECT THE APP

Once the app is selected, a tap will open the previously selected app.

APPUIQUEZ LA FONCTION EN APPUI LONG

Une fois l'application sélectionnée, un simple toucher ouvrira l'application précédemment sélectionnée.

MANTER PRESSIONADO PARA SELECCIONAR O APP

Uma vez selecionado o app, ao tocar, a app previamente selecionada será aberta.



WUUM ONE

Quick Guide

