

PHILIPS




AMBILIGHT tv

Quick Start Guide



9000/9010/9050/9060 Series




Tool needed
for assembly




43" (M4xL12) : x7
50"/55" (M4xL12) : x4
65" (M4xL16) : x4
50"/55"/65" (M5xL16) : x3




1 43"/50"/55"




65"




2





3






A Desk Placement




B Wall Placement





43" (M4xL12) x3
50"/55"/65" (M5xL16) x3



43"/50"/55" (M4xL12) x4
65" (M4xL16) x4



Recommended Wall Distance



4

Get Connected




www.philips.to/smartTV

The Philips Smart TV app lets you switch channels and adjust the volume - just like a remote control.

5


Register and Support



www.philips.com/TVsupport


Register your TV, find out more, download the user manual and get support

1




To install batteries, slide the battery door up.

2




Use 2x AAA LR03 1.5V (included)

3




Slide battery door back in place.

1 2 3 4













English

Read the safety instructions.

Български

Прочетете инструкциите за безопасност.

Čeština

Prečtěte si bezpečnostní pokyny.

Hrvatski

Pročitajte sigurnosne upute.

Dansk

Læs sikkerhedsforskrifterne.

Deutsch

Lesen Sie die Sicherheitshinweise.

Ελληνικά

Διαβάστε τις οδηγίες ασφαλείας.

Eesti

Lugege ohutusõudeid.

Español

Lea las instrucciones de seguridad.

Français

Lisez les consignes de sécurité.

Italiano

Leggere le istruzioni di sicurezza.

Қазақша

Қорғаныстық нұсқаулар.

Latviešu

Izlasiet drošības norādījumus.

Lietuvių

Perskaitykite saugos instrukcijas.

Magyar

Olvassa el a biztonsági utasításokat.

Nederlands

Lees de veiligheidsvoorschriften.

Norsk

Les sikkerhetsforskriftene.

Polski

Zapoznaj się z instrukcjami bezpieczeństwa.

Português

Leia as instruções de segurança.

Română

Citiți instrucțiunile de siguranță.

Русский

Читайте инструкции по технике безопасности.

Srpski

Pročitajte bezbednosna uputstva.

Slovenščina

Preberite varnostna navodila.

Slovenský

Prečítajte si bezpečnostné pokyny.

Suomi

Lue turvaohjeet.

Svenska

Läs säkerhetsinstruktionerna.

ภาษาไทย

โปรดอ่านคำแนะนำด้านความปลอดภัย

Türkçe

Güvenlik talimatlarını okuyun.

Українська

Читайте інструкції з техніки безпеки.

العربية

قراءة تعليمات السلامة.

עברית

קראו את הוראות הבטיחות

FSC Logo


H:12mm



FEUILLE

Séparer les éléments avant de trier





3 sec


PAIR




PAIR



alexabuilt-in



43"/50"/55"/65"



COMMON INTERFACE

USB 2

Headphones

USB 1







POWER (EU)

POWER (UK)

SAT (EU)

TV ANTENNA


HDMI 1

HDMI 2 ARC/eARC

HDMI 3/4


DIGITAL AUDIO OUT


NETWORK






















B

1

65"



2



X (mm)

Y (mm)

Screw Size

Screw Length (mm)

43" / 108

100

200

M6

10-12

50" / 126

200

300

M6

10-16

55" / 139

200

300

M6

10-16


65" / 164

300

300

M6


12-20




L

T


Recommended Wall Distance



7-10 cm









All registered and unregistered trademarks are property of their respective owners. Specifications are subject to change without notice. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license. This product has been manufactured by and is sold under the responsibility of TP Vision Europe B.V., and TP Vision Europe B.V. is the warrantor in relation to this product. 2025 © TP Vision Europe B.V. All rights reserved. www.philips.com/welcome