

Mechanical Action Buttons	Razer Mecha Tactile Action Buttons
Multi-Function Buttons	<ul style="list-style-type: none">• 4 Mouse Click Back Paddles• 2 Claw Grip Bumpers
Triggers	2 Hall Effect Analog triggers with Mouse Click trigger stops
Thumbsticks	Anti-drift Hall Effect analog thumbsticks
Carrying Case	Carrying case for controller and accessories
USB Cable	3 m / 10 ft USB C to USB A
Color	<ul style="list-style-type: none">• Black• White



RAZER INSIDER

Have a question? Ask the Razer Community for help! (English only)

ENTER INSIDER



NEED HELP?

Get support by phone, chat, or email

CONTACT SUPPORT