



裁切线


### Steps for using the vacuum freshdrawer




Step 1




Step 2




Step 3



Step 4



Step 5



Step 6

135 mm

- Step1, Initial state.
- Step2, Raise the handle control lever.
- Step3, After the air enters and the pressure inside and outside is balanced, gently pull it out.
- Step4, Remove the required items.
- Step5, Gently pull in the vacuum drawer.
- Step6, Press down and lock the control lever to automatically activate the vacuum pumping function.

100 mm

## 技术要求

1. 所有印刷符号和图案为黑色;
2. 严格按照1:1制版印刷;
3. 尺寸100X135mm未标注公差按照GB/T 1804-m;
5. 印刷内容清晰无缺陷、内容正确、胶粘平整,切角为直角;
6. 成品背面附不可移不干胶,粘贴在箱体内部,不翘曲、不脱落,相关性能应符合企标Q/HKB J04140《不干胶铭牌标签》相关要求;
7. 符合Q/HKBJ16001《零、部件及原材料中有害物质含量规定》;
8. 颜色及整体效果必须经过研发部确认后方能生产,产品检验以封样件为准。

**Hisense**

名称

唛头标签

设计

徐婷

审核

陈思萌

版本号

比例

图号/物料号

B08210254/4297953

材料

0.05mm白色PET

批准

白莉

日期

2023-06-21

更改单编号

首次使用产品

BCD-605WP1BKG1/HC4(H2)