
# **MX MASTER 4**

Setup Guide Setup Guide





### **CONTENTS**


English	Español	31
Français	Português	45

### **KNOW YOUR PRODUCT**

### **TOP VIEW**








#### WHAT'S IN THE BOX

- 1. MX Master 4
- 2. USB-C dongle
- 3. User documentation




### CONNECT YOUR MX MASTER 4 WITH BLUETOOTH®

### STEP 1: TURN ON YOUR MX MASTER 4 TO CONNECT IT


Find the switch on the bottom of your mouse and switch it to the **ON** position.

If there is no power, try charging the mouse.



#### STEP 2: THE LED SHOULD BLINK FAST

If not, press and hold the Easy-Switch button (on the back of the mouse) for 3 seconds. When the light begins blinking, the mouse is ready to pair with your computer.



## STEP 3: COMPLETE THE PAIRING TO YOUR COMPUTER

On your computer find the *Bluetooth*® settings menu and connect your MX Master 4 from there.



#### **STEP 4: INSTALL LOGI OPTIONS+**

Logi Options+ is a powerful and easy-to-use application that enhances your experience using Logitech devices by enabling you to customize them to work how you want.




## CONNECT YOUR MX MASTER 4 WITH THE USB-C RECEIVER

### STEP 1: TURN ON YOUR MX MASTER 4 TO CONNECT IT

Find the switch on the bottom of your mouse and switch it to the ON position.


If there is no power, try charging the mouse.




## STEP 2: PLUG THE WIRELESS RECEIVER INTO YOUR COMPUTER USB PORT

Your device should now be connected.

If not, press and hold the Easy-Switch button (on the back of the mouse) for 3 seconds. When the light begins blinking, the mouse is ready to pair with your computer.





#### **STEP 3: INSTALL LOGI OPTIONS+**

Logi Options+ is a powerful and easy-to-use application that enhances your experience using Logitech devices by enabling you to customize them to work how you want.



#### **DIMENSIONS**

Width: 88.35 mm Height: 128.15 mm Depth: 50.8 mm

www.logitech.com/support/mxmaster4