


MCHOSE



— V9/V9 Pro USER MANUAL —
GAMING HEADSET


· PRODUCT OVERVIEW



- Power Button**
Power On/Off: Long press for about 3s
Connection Mode Switch: Double-click
Game/Music Mode Switch: Triple-click
Play/Pause: Single click
Answer/End Call: Single click
Reject Call: Long press for about 1.5s
- Indicator Lights**
BT Waiting for Connection: Red and blue lights flash alternately
2.4G Waiting for Connection: Red and green lights flash alternately
Charging: Red light stays on
Fully Charged: Blue light stays on
- Microphone Button**
Microphone On/Off: Single click
- Volume Wheel**
Volume +: Slide upwards
Volume -: Slide downwards

Visit the website: <https://www.mchose.store/pages/firmware-2>, and select the installation package for your specific model version to download.

· 2.4G CONNECTION




- ② Press and hold the button to power on
 - ③ Double-click the button to switch to 2.4G mode (Headset announcement: Adapter Mode)
 - ④ The headset will automatically connect to the 2.4G receiver, and the headset indicator light will change to a slow flashing green light.
- Connected → Indicator light: Flashing once every 1.5s
- Not Connected → Indicator light: Flashing alternately

* Receiver pairing (Manufacturer Default: Already paired) : In 2.4G mode, press and hold the [Power Button] and [Microphone Button] until the indicator light flashes white 3 times, when the green indicator light of the receiver stays on, the 2.4G re-pairing is successful.

* During manual pairing, keep the headset as close to the receiver as possible.


· BT WIRELESS



Warm Reminder: After the headset disconnects due to distance, it will automatically reconnect when it comes back within range. If no device is reconnected within 5 minutes, the headset will automatically power off.

BT wireless Factory Reset: Power off the headset in Bluetooth mode, then press and hold for 8s until the indicator light flashes white three times. The reset is successful, and you can reconnect and pair again. (If there is a connection history with the device, please manually delete it.)

· SOUND CARD MODE



1. With the headset powered on, connect the cable to the headset and plug it into the computer. The headset will automatically switch to Sound Card Mode.
2. You can double-click the button to cycle between [Adapter Mode] / [BT wireless Mode] / [Sound Card Mode] .

· HEADSET CHARGING



- Low Battery: Red indicator light flashes slowly
- Charging: Red indicator light stays on
- Fully Charged: Blue indicator light stays on

Note: This device has been tested and complies with the limits for Class B digital devices under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations.

This device generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception (which can be determined by turning the device off and on), we encourage the user to try one or more of the following measures to correct the interference:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the responsible party could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

WARRANTY CARD


Thank you for purchasing our product. Please contact us if there are any quality issues within the warranty period. Please provide this warranty card so we can provide comprehensive after-sales service.

Product Items: _____ Customer Name: _____

Serial NO. : _____ Contact Address: _____

Purchase Date: _____ TEL / E-mail: _____

Purchase Channel: _____ Postal Code: _____



Executive standard: GB4943.1-2022